



Small Entrance Panel Touch

User and installation manual

bticino



Contents

General information	5
Warnings and recommendations	5
Warnings and consumer rights	5
Fundamental concepts	6
Naming of the devices	6
Community	6
Call addressing procedures	7
Numeric call (using the standard address of the community)	7
Alphanumeric call (using Alias)	8
Call using alphanumeric alias	8
Contacts	8
Configuration	8
Lift function	9
Fire-fighting	9
OnVif IP cameras	9
Alphanumeric call (using alphanumeric alias)	10
Alphanumeric call (using contact alias in the address book)	10
Lift Control Function	10
Fire-fighting	10
OnVif IP cameras	10
Front and rear view	11
Dimensional data and installation heights	14
Installation	15
Uninstall	19
Activation	20
Example diagrams	21
Ethernet connection	23
Ethernet connection to the Standard PoE switch	24
Fiber optic riser connection (case of higher bandwidth demand)	25
Intercom function	26
Lift control 1 - Lift control with protocol interface 375010, 1 riser, 1 entrance panel	27
Lift control 2 - Lift control with protocol interface 375010, more risers, 1 entrance panel	28
Lift control 3 - Lift control with protocol interface 375010, 1 riser, more entrance panels	29
Lift control 1 - Lift control with lift control interface with relay 375013, 1 riser, 1 entrance panel	30
Lift control 2 - Lift control with lift control interface with relay 375013, more risers, 1 entrance panel	31
Lift control 3 - Lift control with lift control interface with relay 375013, 1 riser, more entrance panels	32
Available functions	33
Use of the device	34
Introduction	35
Home page	36
Functions	37
Call a IU	37
Answering machine	42
Messages and advertising	43
Call a GS	44

Accesses	45
Access using Access Code	45
Access using badge or card	47
Access using Face recognition	48
Configurations using the device (Settings)	49
Address	51
Setting	52
Access code	53
Guard station	54
Door lock	55
Display & Volume	56
Lift Control	57
Ringtone	58
Face settings	59
Background	61
Information	62
Language	63
User guide	64

General information

Warnings and recommendations

It is important to read this manual carefully before proceeding with the installation.

The warranty becomes automatically void in case of negligence, improper use, tampering by unauthorised personnel.

The Entrance Panel must not be exposed to water drops or splashes; it must be used only on IP DES digital systems.

Warnings and consumer rights



Read carefully before use and keep for future reference.



Touching the units with wet hands is forbidden.

Using liquid cleaners or aerosols is forbidden.

Blocking the ventilation openings is forbidden.

Modifying the devices is forbidden.

Removing protective parts from the devices is forbidden.

Exposing the unit to water drops or splashes is forbidden.

Installing the units near heat/cold sources is forbidden.

Installing the units near harmful gases and powders is forbidden.

Fastening the units on unsuitable surfaces is forbidden.



Danger of electrical shock.



Risk of devices falling because the surface on which they are installed collapses or inappropriate installation.

Switch the power supply OFF before any work on the system.



Caution: Installation, configuration, starting-up and maintenance must be performed exclusively by qualified personnel.

Check that the wall installation has been carried out correctly according to the installation instructions.

Check that the unit installation complies with the standards in force.

Connect the power supply wires as indicated.

Use only the items indicated in the technical specifications for any system expansions.

Warning: in case of a power failure, the device does not work and cannot be reached, any collection of personal data is interrupted.

Fundamental concepts

The device cannot be activated individually but must follow a general configuration found on the DES Server.

The DES Server is configured using a PC connected to the same LAN.

Once configured and activated, the DES Server makes available the configuration of local devices (Internal Unit, Entrance Panel, Guard Station, etc.)

When switched on, the device searches for a configuration (address book) on the DES Server and acquires it.

Naming of the devices

In this manual, for easy reading, the abbreviated device name is used as in the list:

- IU: Indoor Unit
- EP: Entrance Panel
- GS: Guard Station
- SD: Server DES
- SEP: Small Entrance Panel
- AB: Address book
- SW: IP DES SYSTEM

Community

The term Community means the housing complex reproduced in the project design made using the SW.

The structure in its maximum extension includes:



Call addressing procedures


On the basis of data recorded in the system phonebook and the Community structure the calls can be made using various methods:

- **numeric call (using the standard address of the community);**
- **alphanumeric call (using Alias);**

Numeric call (using the standard address of the community)

To make this type of call you must know the address of the person being called, which depends on the community structure, for example:

- to call the IU highlighted in the diagram from the «A» EP, enter the corresponding address «11010402»;
- to call the IU highlighted in the diagram from the «B» EP, enter the corresponding address «010402», as the IU is positioned inside building 1 and therefore it is sufficient to type the Riser, Floor and Apartment number.



Note: during the configuration phase, the number of digits to be used for each call sector (Area/Building/Riser/Floor/Apartment) must be set.

Example: I have to call an apartment inside building 2

- if there are from 1 to 9 buildings in the area, I must enter «2» (one digit used for the Building call sector);
- if there are more than 10 buildings in the area, I must enter «02» (two digits used for the Building call sector).

The system will automatically show the correct number of digits to type and which data to enter on the basis of the EP position you are calling from, for example Area (2 01 06 02) or Building (01 06 02)

System configuration (default)

Areas 9, Building 99, Riser 99, Floor 99, Apartment 99

It is possible to modify the limits using the SW (see SW manual for details)

Alphanumeric call (using Alias)

The Alias is an alphanumeric code that replaces the community address created through the software.

The default alias is the same as the address in the Community*. However, this can be changed using the SW and can be of two types:



Call using alphanumeric alias

The alphanumeric alias can be used on all entrance panels, internal units and guard stations. To make the call, enter the full alphanumeric alias in the device call menu - -> B12

Call using contact alias in the address book

The address book contact alias can be used on all internal units and guard stations, but only on entrance panels with touch display.

To make the call, use the appropriate address book button (icon) in the call menu of the device and select the desired contact (JOHN SMITH), or enter the contact alias using the auto-complete function - -> JOHN SMITH

Contacts

The positioning of the objects in their respective locations also allows the creation of the contact lists that they can manage: for example, an EP positioned in the building will only have the contacts of the same building.

The GS will always have the complete contact list of the entire community

Configuration

Address book, created using the SW, containing the addresses of all the system devices.

Lift function

The Lift Control function consists of the ability to interact with the lift system through calls and commands from the DES IP video door entry system.

The operating mode of the lift depends on its control system (BTicino cannot operate the lift but only send commands, which are interpreted and executed).

Safety must be guaranteed by an access control system or by the lift itself.

The lift control function can be realised in two modes:

- The first is through protocol commands on RS485.
Using the interface 375010, the IP DES video door entry system sends commands to the lift control centre to simulate a lift call.
For more information, see the “Lift Interface Software Manual, item 375010”.
- The second mode is through dry contact commands.
The DES IP video door entry system opens and/or closes contacts (output contacts from interface 375013). Lift calls are simulated when these contacts (correctly connected to the lift system) are opened or closed.
Interface 375013 must be added as a device in the Community.
After this, it will be necessary to configure the parameters in the [Lift Control function](#) page.

You can see some examples of connection diagrams in the manuals of the IP devices.

Fire-fighting

Enables the door lock opening function in case of fire.

The Fire-fighting function allows the automatic opening of EP door locks in the event of a fire.

The use of this function requires a clean contact in the GND FIRE-FIGHTING input clamp from the fire fighting system.

It is necessary to enable the function in Settings

OnVif IP cameras

OnVif IP cameras wired on the same network as the IP video door entry system with video surveillance of public and/or private areas.

What discussed in the previous sections is not applicable to all devices. Below is a list showing their applicability.


	Alphanumeric call (using alphanumeric alias)	Alphanumeric call (using contact alias in the address book)	Lift Control Function	Fire-fighting	OnVif IP cameras
373001	✓	✓	✓	✗	✓
373002	✓	✓	✓	✗	✓
373003	✓	✓	✓	✗	✓
373004	✓	✓	✓	✗	✓
373005	✓	✓	✓	✗	✓
373006	✓	✓	✓	✗	✓
373007	✓	✓	✓	✗	✓
373008	✓	✓	✓	✗	✓
374000	✓	✓	✓	✓	✗
374001	✓*	✗	✓	✓	✗
374002	✓	✓	✓	✓	✗
374003	✓*	✗	✓	✓	✗
374004	✗	✗	✓**	✓	✗
374005	✓	✓	✓***	✓	✗
374006	✗	✗	✓**	✓	✗
375000	✓	✓	✗	✗	✓

*NOTE: function only available with numbers and letters between 0-9 and A-I


**NOTE: function only valid with contact interface 375013

***NOTE: function only valid with contact interface 375013 or with interface 375011, but only in SLAVE mode

Front and rear view



1. Light sensor
2. LED for the shooting field lighting
3. Camera
4. Display 4.3" (touch screen)
5. Badge reader for door lock opening
6. Loudspeaker
7. Locking screw
8. Microphone




- 9. RJ45 Connector (*)
- 10. Not used
- 11. Connection clamp
- 12. Tamper switch
- 13. Mounting bracket
- 14. USB Connector (not used)
- 15. Reset the "local access code" and the "setting access code" to the factory values
- 16. Not used

(*) This device does not support standard POE power supplies, but only POE power supplies identified with item no. 375002.

Connect the cat5/5e/6 FTP or cat5/5e/6 UTP cable with ferrite supplied to the connector

Small Entrance Panel Touch



User and installation manual



Connection clamps	
LOCK+	connection and control of the electric door lock
LOCK-	(12V - 4A impulsive 30 Ohm max)
SENSE	door lock status signal input (dry contact)
GND - +12V	access control devices power supply
OPEN	third party access control signal input for door lock opening (+12Vdc pulse)
GND	system common ground terminal for third party connection
Door OPEN - GND	local door lock release pushbutton connection
FIRE Linkage - GND	local door lock release pushbutton connection for firealarm system
NO	
C	interlocked dry contact for electric door lock connection
NC	
DC24V	additional power supply clamps (not polarized)


It is possible to display some wiring diagram examples in the [Example diagrams/functions](#) section

Dimensional data and installation heights



(*) Recommended height, unless different regulations are specified.



Installation



Attention: The wrong wiring of the Ethernet cable connecting the device to the Poe Switch 375002 could damage the device itself.
The RJ45 cable must be at least 200 mm long.


Small Entrance Panel Touch

User and installation manual




Small Entrance Panel Touch

User and installation manual




Small Entrance Panel Touch


User and installation manual



(*) Adjust the tamper screw so that it presses the tamper switch of the device and activates the anti-theft function in case of removal sending an alarm to the GS.



Uninstall




Activation

After configuring the MAC address of the device in the SD, when switched on, the device searches for a configuration (address book) on the DES Server and acquires it.

NOTE: if the device were already configured in the past, it must be reset.

After rebooting, the device will configure itself

If the automatic activation of the device is unsuccessful, warning messages and manual activation modes may appear.



A Not to be used

B Button allowing manual entry of the server IP address or installation code. By entering one of the two described parameters, it is possible to force the configuration of the device by putting it into forced communication with the server.

NOTE: to display the IP address, see the "Community Network Settings" menu of the SW, to display the installation code, see the "Device/Management" menu of the SW.

C Button to test the activation of the device

1. Touch to manually enter the server IP address or the system access code

IP address



Installation code



1A. Enter the IP address of the server.


1B. Enter the installation code

Example diagrams

A - Diagram with power supply by BTicino PoE Switch

CABLES LEGEND	LAN PoE Standard	LAN PoE BTicino	LAN Ethernet	Copper cables	2 x Copper cables

It is possible to use two different types of connection according to installation situation:



Caution:

- connect the devices only to the PoE 375002 switches. No other PoE switches are permitted.
- only item 373008 can be connected to an IEEE 802.3at standard PoE switch (POE+)
- item 375001 must be connected to the LAN network, not to PoE switches
- connect the UP LINK port of the 375002 to a suitable network port, never to a PoE port.
- use a cat5/5e/6 FTP or cat5/5e/6 UTP cable. If using a UTP cable, use the supplied ferrite.

Note:

- to connect the devices it is possible to use both types of wiring (diagram A or diagram B) or even mixed ones.
- maximum length of every LAN permanent link line = 90 m.

Small Entrance Panel Touch


User and installation manual



B - Diagram with local power supply

CABLES LEGEND	LAN PoE Standard	LAN PoE BTicino	LAN Ethernet	Copper cables	2 x Copper cables

It is possible to use two different types of connection according to installation situation:



Caution:

- connect the devices only to the PoE 375002 switches. No other PoE switches are permitted.
- only item 373008 can be connected to an IEEE 802.3at standard PoE switch (POE+)
- item 375001 must be connected to the LAN network, not to PoE switches
- connect the UP LINK port of the 375002 to a suitable network port, never to a PoE port.
- use a cat5/5e/6 FTP or cat5/5e/6 UTP cable. If using a UTP cable, use the supplied ferrite.

Note:


- to connect the devices it is possible to use both types of wiring (diagram A or diagram B) or even mixed ones.
- maximum length of every LAN permanent link line = 90 m.

Small Entrance Panel Touch

User and installation manual


Ethernet connection

CABLES LEGEND LAN PoE Standard  LAN PoE BTicino  LAN Ethernet  Copper cables  2 x Copper cables 



Attention: check the installation [precautions](#) and [notes](#)

Ethernet connection to the Standard PoE switch




Attention: check the installation [precautions](#) and [notes](#)

Small Entrance Panel Touch

User and installation manual


Fiber optic riser connection (case of higher bandwidth demand)

CABLES LEGEND	LAN PoE Standard	LAN PoE BTicino	LAN Ethernet	Optical fiber	Copper cables	2 x Copper cables
---------------	------------------	-----------------	--------------	---------------	---------------	-------------------



Attention: check the installation [precautions](#) and [notes](#)

Lift control 1 - Lift control with protocol interface 375010, 1 riser, 1 entrance panel



Attention: check the installation [precautions](#) and [notes](#)

Small Entrance Panel Touch


User and installation manual




Lift control 2 - Lift control with protocol interface 375010, more risers, 1 entrance panel

CABLES LEGEND LAN PoE Standard LAN PoE BTicino LAN Ethernet Copper cables n° 2 Copper cables

MONTANTE 1




MONTANTE 2



Attention: check the installation [precautions](#) and [notes](#)

Lift control 3 - Lift control with protocol interface 375010, 1 riser, more entrance panels

CABLES LEGEND LAN PoE Standard LAN PoE BTicino LAN Ethernet Copper cables n°2 Copper cables



Attention: check the installation [precautions](#) and [notes](#)


Small Entrance Panel Touch

User and installation manual



Lift control 1 - Lift control with lift control interface with relay 375013, 1 riser, 1 entrance panel

CABLES LEGEND	LAN PoE Standard	LAN PoE BTicino	LAN Ethernet	Copper cables	n° 2 Copper cables
---------------	------------------	-----------------	--------------	---------------	--------------------



Attention: check the installation [precautions](#) and [notes](#)


Small Entrance Panel Touch

User and installation manual


Lift control 2 - Lift control with lift control interface with relay 375013, more risers, 1 entrance panel

CABLES LEGEND LAN PoE Standard LAN PoE BTicino LAN Ethernet Copper cables n° 2 Copper cables

MONTANTE 1



MONTANTE 2



Attention: check the installation [precautions](#) and [notes](#)


Small Entrance Panel Touch

User and installation manual



Lift control 3 - Lift control with lift control interface with relay 375013, 1 riser, more entrance panels

CABLES LEGEND	LAN PoE Standard	LAN PoE BTicino	LAN Ethernet	Copper cables	n°2 Copper cables
---------------	------------------	-----------------	--------------	---------------	-------------------




Attention: check the installation [precautions](#) and [notes](#)

Small Entrance Panel Touch

User and installation manual

Available functions

CABLES LEGEND	LAN PoE BTicino 	LAN Ethernet 	Copper cables 
---------------	---	---	---



Attention: do not directly connect PoE ports to an unsuitable network interface, such as a device powered by a different voltage. Connect the UP LINK port to a suitable port, never to a PoE port.

Note: to connect the devices it is possible to use both types of wiring (diagram A or diagram B) or even mixed ones.

Use of the device

After installing the EP it is possible to:


- [Call a IU](#)
- [Call a GS](#)
- [Access using Access Code;](#)
- [Access using badge or card;](#)
- [Access using Face recognition;](#)
- [Set the advanced parameters](#)

Introduction

After the installation and connection of the device, it is necessary to configure it and create the Community structure. For details see Server DES Software manual.



- Step 01 Community VLAN network creation
- Step 02 Community structure definition
- Step 03 Community structure creation
- Step 04 Device MAC address registration
- Step 05 Community customisation
- Step 06 Saving of passwords
- Step 07 Registration of the Community on the Installer's Cloud
- Step 08 Forwarding of the address book to the DES Server
- Step 09 Installation of the devices
- Step 10 Activation of the devices
- Step 11 System test
- Step 12 Update of the devices



Home page

This page may show different content according to the configuration and systems connected to the device.

The Home Page, with all the functions enabled, is shown below.



A Current time

B Function keys



Call a IU



Call a GS



Access using Face recognition



Access using Code



Settings

1. Scroll to display the complete menu bar

Functions



Call a IU


It is possible to call an IU in different ways:

- [call using the address in the Community;](#)
- [call using the Alias \(alphanumeric code\);](#)
- [call using the Phonebook.](#)

The call mode depends on how the community has been configured using the SW. [For details see Fundamental concepts](#)

If the device has been positioned in the structure at Apartment level, when the Guest call key is pressed, the call is directly sent to the IU.

If the device has been positioned at a higher level (e.g. building, riser, etc.), the IU can be called in different ways:




1. Touch to select the function

Call using the address in the Community



Call using the Alias (alphanumeric code)



A Delete typing

B Change the type of keypad (numbers/letters)


C Send a call

2. Enter the address in the IU Community, the device helps you by showing the fields to be entered (e.g. 1 01 04 02)
3. Touch to send the call

2. Enter the alphanumeric code created using the DES Server software (e.g. B12)
3. Touch to send the call

Note: in the alphanumeric mode, the default code corresponds to the address in the Community as long as the Server DES software has not altered it in the AB

Call using the Phonebook




2. Enter the Alias saved in the AB (e.g. JOHNSMITH) directly.
In this mode autocompletion is active
3. Touch the suggested contact to send the call
4. Touch to open the phonebook containing the contacts you can call.
E.g. a Building EP will display only its building contacts.
5. Touch the code to send the call



A Call duration


B Address in the IU Community*

***Note:** the caller display depends on how the community has been configured using the software. For details see [Fundamental concepts](#)



6. Touch to end the call


When the IU does not answer a message can be recorded (see [Answering machine](#))




A message indicates that the call is ended

Answering machine

If the IU does not answer within 30 seconds, it is possible to leave a photo with a voicemail.



1. Touch to record a photo message




2. You have 30 seconds to leave a message.
The IU will receive your image and the voice messages
3. Touch to end

Messages and advertising

When messages are sent to the community via SW, the device displays them when the screen saver is activated.

Community message	messages coming from the Facility manager about the Community
Emergency notification	emergency messages, coming from the Facility manager





Messages displayed as screen saver



Call a GS



This function allows to call the reference GS set in the [Settings/Guard station](#) section



1. Touch to select the function

A GS address*

**Note: the caller display depends on how the community has been configured using the software. For details see [Fundamental concepts](#)*



2. Touch to end the call

A message indicates that the call is ended

Accesses

It is possible to access the building in different ways:



Access code

Access by entering a local code, an apartment personal code* or a panic code



Key card

Access using a badge or card configured with SW



Face recognition

Access by face recognition. Need to record the face using SW (only for item 374000)


**Correct operation requires the configuration of the code from the IU and a resident associated with the apartment in the SW (see SW Community/Person profile management)*

Note: If the system is set up to manage the lift control function (only with interface 375010), opening the gate will also activate at the same time the configured lift call function.





Access using Access Code

Using this function it is possible to access the building by typing an Access code. The Access Code is set in the [Installation\Access code\Local](#) section



1. Scroll to display the function to select
2. Touch to select the function



3. Enter the local access code (ask the plant manager for your code, available in the device parameters section of the SW) or the personal access code or panic code.

4. Touch to confirm

Beeps and visual warnings will confirm that the code has been recognised and the door lock will open.

Personal access code opens the last EP of my community, i.e. the EP closest to the apartment, chosen from those to which I have access.

Example: if they are enabled to all the accesses (complete Area/Building/Riser/Floor/Apartment structure) I open the Apartment EP.

This code does not work on community/area/building EPs

Panic access code: opens the door and at the same time sends an alarm message to the guard station.

Example: if a criminal forces me to forcibly open the door

The local access code opens community EPs, with the exception of apartment SEPs and EPs

Note: for safety reasons, modify the code.

Note: to activate the code, there must be a resident associated with the apartment in the SW (see SW manual)




Access using badge or card

Using this function you can access the building using a badge or a card. To use this function, the badge or card must be saved in the system via SW.



1. Move the badge or card on the reader





Beeps will confirm that the badge/card has been recognised and the door lock will open.



Access using Face recognition


Using this function, the EP camera will recognise your face and you can enter the building automatically without entering a code.

To use this function, your face must be saved in the system via SW.



If the **proximity sensor is active** the function will activate automatically, otherwise:

1. Touch to select the function
2. Position yourself so that the camera can frame your face and the system activates the recognition process.



Beeps will confirm that the face has been recognised and the door lock will open.

Configurations using the device (Settings)

In this section, it is possible to perform a wide range of configurations that will enable you to make the most of your EP.

Access to this section is protected by an installer password which can be set by the software



1. Scroll to display the complete menu bar
2. Touch to access the Settings section




3. Enter the installer password to access the configuration section (ask the plant manager for your password, available in the device parameters section of the SW)

Caution: Save passwords in a safe place that is always accessible.
(Cloud backup activation recommended)

If both the SD and the backup are unavailable, it will not be possible to retrieve the passwords.

Note: The passwords of the devices incorrectly activated in DEMO mode are: 2000 (EP) and 1111 (IU and GS)

4. Touch to confirm




5. Scroll to display all the functions
6. Touch the icon for the desired configuration, choosing among:


	Address	It displays various device parameters and performs the reset command
	Setting	It enables different functions
	Access code	It sets the menu access installer password Settings and local access Code to open the gate
	Guard station	It sets the EP reference GS
	Door lock	It sets different parameters of the EP door lock
	Display & Volume	It sets some display parameters and the ringtone volume
	Lift Control	It sets the Lift control system parameters
	Ringtone	It displays the ringtones
	Face settings	It sets the parameters for the Face Recognition
	Background	It sets the interface background
	Information	Visualizza varie informazioni sul dispositivo
	Language	imposta la lingua dell'interfaccia
	User guide	It displays the QR code to download the manual

Address

In this section, it is possible to display the different device parameters. It is also possible to restore the factory settings of the device.



1. Touch to reset the device




2. Touch to confirm

Warning: after confirmation, all customisations will be deleted and the parameters will be restored to factory values

Setting

In this section it is possible to enable different types of functions.




1. Touch to enable the function
2. Touch to save the setting

Fire linkage	<u>It enables the Fire-fighting function</u>
Lift control enable	<u>It enables the Lift control</u>
Screen saver enable	It enables the screen saver
Call forwarding enable	It enables the call forwarding to the GS
Tamper alarm enable	It enables the EP tamper alarm, to protect the EP from removal by intruders
Local access code	It enables the customised local code to access the building
Proximity sensing enable	It enables the proximity sensor to activate automatically the display and its functions
Face enable	It enables the Face Recognition

Access code

In this section it is possible to set the installer password to access the Settings menu and the access Code to enter the building


Settings



1. Enter the old installer password
2. Enter the new installer password
3. Enter again to confirm

Local

Note: This entry does not appear if the device is installed as an apartment EP




1. Enter the new code
2. Enter again to confirm

Guard station

In this section it is possible to set the EP reference GS.

The reference GS intercepts and manages the calls to the IU or anyone called directly by pressing the pushbutton on the Home page (see the [Call a GS](#) section)




A Address of the current reference GS

1. Touch to modify the reference GS
2. Select the new GS
3. Touch to save the setting

Door lock

In this section it is possible to set different parameters of the EP door lock



A It restores the factory settings

1. Door Status


The Door Status function allows to receive door status notifications, and therefore a warning when the door is left open.
To use this function, a clean contact in the GND SENSE input clamp is required.
Touch to set a door status alarm:
NO = sends an alarm when the contact remains open for more than 2 minutes
NC = sends an alarm when the contact remains closed for more than 2 minutes
Not used = never sends alarm
The alarm is displayed on both the SSDES and GS
2. Lock

The lock connected to the Lock+ / Lock- clamps can be controlled using pulse commands

Or
3. The lock connected to the Lock+ / Lock- clamps can be controlled using timed commands
4. Enter the contact activation time in seconds
5. Touch to save the setting

Display & Volume


In this section it is possible to set some display parameters and adjust the ringtone volume



- A It adjusts the brightness (backlighting)
 - B It adjusts the ringtone volume
 - C It adjusts the call volume
 - D It adjusts the tone volume when a key is pressed
 - E It adjusts the screen saver activation time
 - F It adjusts the activation time of the display switch off
 - G Set the time within which it will be possible to leave a message in the answering machine. This time is connected with the ringing time (default 35 seconds). E.G.: if the time is set to 5 seconds, the ringing time will be 30 seconds.
 - H It restores the factory settings
1. Touch to adjust the parameters
 2. Touch to save the setting

Lift Control


Network mode



1. Select if a lift control interface 375010 is used
2. Select the floor where the EP is located
3. Enter the IP address of the Master EP

It is possible to display some wiring diagram examples in the [lift control](#) section
For more information, see the «Lift Control Interface item 375010 software manual»

IP-Relay mode




1. Select if a lift control interface 375013 is used.
2. Select the floor where the EP is located

It is possible to display some wiring diagram examples in the [Lift control](#) section
For more information on the use with interface 375013 see "IP DES SYSTEM software manual".

Ringtone


In this section it is possible to listen to the tones associated to the different types of ringtones or other.




- A Alarm tone
 - B Call in progress tone (ringback)
 - C Confirmation key tone
 - D Ringtone not used (future use)
1. Touch to listen to the tone


Face settings

In this section it is possible to set some Face Recognition parameters



- A Camera operating modes:
2D - in this mode, the depth of the image is not checked, and so showing a photograph opens the EP lock
3D - in this mode, the depth of the image is checked, so recognition is only confirmed if someone is in front of the EP (DEFAULT)
Colour - in this mode, the face is only checked by the colour camera (DAY)
Infrared - in this mode, the face is only checked by the infrared camera (NIGHT)
- B *Sets the level of face recognition accuracy and therefore the degree of security.
 0= lower level of accuracy and security
 0.8= higher level of accuracy and security (higher possibility of failed recognitions)
- C Set the distance for the face recognition
- D Enter the number of recognition points to accept the face
- E Enter the minimum image quality to accept the recognition
- F *Maximum angle of face rotation (left/right in relation to the frontal position), for which facial recognition is performed.
 If the rotation is greater, the face is not recognised.
- G *Maximum angle of face inclination (left/right in relation to the frontal position), for which facial recognition is performed.
 If the inclination is greater, the face is not recognised.
- H *Maximum angle of face inclination (up/down in relation to the frontal position), for which the facial recognition is performed.
 If the inclination is greater, the face is not recognised.






- I* Enter the distance from the proximity to activate the recognition function
- J* Enter the time from when the Home Page appears to when the Face recognition function starts
During the face recognition, any other operation is inhibited, even the call.
This time is important if the Face recognition is unsuccessful. You must thus set a time which is long enough for you to be able to call the IU before the Face recognition function reactivates.
- K* Restore the factory settings

***Note:** Only change these parameters if absolutely necessary

Background

In this section it is possible to set the interface background




1. Select the background
2. Touch to save the setting

Note: it is possible to select other backgrounds or create new ones using the SW

Information

In this section it is possible to display different information on the device




A Device address

B Item code

C Versions of the different device components

Language


In this section it is possible to set the interface language



1. Touch to open the language selection panel
2. Select the language
3. Touch to save the setting

User guide

In this section it is possible to download this manual using the QR code



1. Using a smartphone, scan the QR Code
2. Search for the 374000 374001 code
3. Download the manual

Small Entrance Panel Touch

User and installation manual
